


PowerWatch Software

Software Specifications

Type: For PowerWatch (voltage disturbance recorder)

This powerful and easy-to-use power quality analysis software program is developed exclusively for ACR's voltage disturbance recorder, the PowerWatch. With no programming hassles or complex menus, setup and downloading occurs in seconds.



DOWNLOADING AND COMMUNICATING WITH POWERWATCH

Downloading and communicating with the PowerWatch could not be more simple: plug the optical interface cable (LIC-101 cable) into the serial port of your computer and point the other end to the optical port on the PowerWatch. Communication begins immediately. No tools, cards or docking stations are required.



SETUP INFORMATION

The following setup information is displayed in PowerWatch software: voltage disturbance threshold values, site descriptions, filename, start and stop date and time, and the recorder's serial number. Configure the threshold values for each voltage disturbance type and frequency or use the industry standard default values.

DETAILED SITE REPORTS


Detailed site reports are displayed for every voltage disturbance event recorded from the PowerWatch including:

- Hot-to-Neutral and/or Neutral-to-Ground Surges
- Hot-to-Neutral and/or Neutral-to-Ground Sags
- Hot-to-Neutral and/or Neutral-to-Ground Impulses
- Outages
- Frequency Variations

Event #	Start Time	Events	Events	Events	Events
11	10/25/98 11:44	0-Vrms	Open Event	3000	3000
12	10/25/98 12:15:30	0-14V Impulse	-484 Vp	957	957
13	10/25/98 12:15:30	0-Vrms	Open Event	3000	3000
14	10/25/98 04:40:00	0-Vrms	0.5 cycles	13/25/98 12:15:28	13/25/98 12:15:28
15	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000
16	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000
17	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000
18	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000
19	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000
20	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000
21	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000
22	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000
23	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000
24	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000
25	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000
26	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000
27	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000
28	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000
29	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000
30	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000
31	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000
32	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000
33	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000
34	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000
35	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000
36	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000
37	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000
38	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000
39	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000
40	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000
41	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000
42	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000
43	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000
44	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000
45	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000
46	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000
47	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000
48	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000
49	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000
50	10/25/98 04:40:00	0-Vrms	0.5 cycles	3000	3000


STATISTICAL ANALYSIS

A large number of events can be quickly analyzed by using the Quick Summary option. Quick Summary totals all the surge, sag and impulse events and displays all of their occurrences individually in a bar graph format. This format helps determine power quality trends quickly and effectively.



EVENT DISTRIBUTION GRAPH

The Event Distribution Graph plots the magnitude of events against duration on a logarithmic scale, allowing you to determine the importance of the data (a single random event may not be as important as a cluster of events). All 4000 events can be plotted on this graph. Graph hot-to-neutral or neutral-to-ground events or show both in different colours. The CBEMA Curve can be used to determine the importance of each event.



- ### FEATURES
- Powerful and easy to use
 - Quick and simple downloads
 - Detailed site reports for each voltage disturbance type
 - Quick summary option
 - Determine importance of each event

Model#: PW (Full Install) 34-0004
Cat#: PWV-100 (Interface Package) 01-0060